

SAF axle hubodometer mounting

Instructions for mounting hubodometers to any SAF axle with plastic hubcaps.

Please be advised that hubodometers should always be mounted to the appropriate SAF hubodometer hubcap and never be mounted directly to the standard SAF plastic hubcap (as illustrated).

We have recently had incidents of customers drilling a mounting hole directly into the standard hubcap. The standard hubcaps red centre piece is a separate plastic casting and the weight of the hubo can possibly cause this to detach leaving an opening inside the hubcap. This may also potentially void any SAF kilometre based warranty due to the requirement of a working hubodometer.

This service bulletin currently relates (but not limited) to the following SAF axle models brought into Australia; SKRB9019, SKRLB9019, SKRB9022, SKRLB9022, Z19-19, Z9-4218, Z11-3020 and ZL11-3020.

For any questions regarding this Service Bulletin, please contact the SAF-HOLLAND Technical Service Department or your local SAF-HOLLAND representative.

STANDARD HUBCAP
for use without hubodometer



HUBODOMETER HUBCAP



HUBODOMETER HUBCAP
c/w hubo (correct)



STANDARD HUBCAP
c/w hubo (incorrect)

