


GOLD LATCH REPLACEMENT PROCEDURE S



RK-10632

For PH-10RP41, PH-30SA41, PH-30SB41 and PH-30RP41 Pintle Hooks Without a Pin and Lanyard


VERIFY KIT CONTENTS



Kit Contains:

ITEM	PART NO.	QTY
Α	XA-10632	1
В	XB-T-89-4	1
С	XB-11048	2
D	Never-Seez®	1

Never-Seez® is a registered trademark of Bostik, Inc.




PH-30SA41/PH-30SC41 PINTLE HOOKS For additional information, reference XL-PH368 PH-30SB41/PH-30SD41 PINTLE HOOKS For additional information, reference XL-PH365


XL-PH361 Rev B

PROCEDURE

 Grind off head of rivet and discard rivet and latch assembly.




2. Apply Never-Seez® to entire shaft of the new pivot bolt (not on thread).




3. Install the new latch assembly using the new pivot bolt and nut. Tighten nut until it contacts the cast latch and apply an additional 1/4 turn to the nut. Visually verify that a full thread protrudes beyond the nut. If it becomes necessary to remove the lock nut, discard and use the second nut provided in the kit.

DO NOT reinstall a removed lock nut. Always install a new lock nut when removing or replacing latch assembly. A reinstalled nut may not retain properly and could result in an unintended trailer separation.



4. Check the latch for proper operation. It should open and close freely. When closed, the lock handle (A) will rotate and move up until it is flush with the top of the latch.





SAF-HOLLAND USA, Inc. 888.396.6501 Fax 800.356.3929

2

SAF-HOLLAND Canada Limited 519.537.3494 Fax 800.565.7753 Western Canada 604.574.7491 Fax 604.574.0244

SAF-HOLLAND International, Inc. 616.396.6501 Fax 616.356.1511